



RE400a

Owner's Guide

HIFIMAN RE400a Owner's Guide

Thank you for purchasing the HIFIMAN RE400a, a high performance, in-ear headphone designed to provide excellent sound quality and comfort while on-the-go. Designed for Android smartphones, RE400a is a headset with in-line control that will enhance your experience of listening to music with your mobile device. HIFIMAN is one of the leading brands of high performance headphones, amplifiers and portable music players in the world so you can be assured of exceptional quality and value.

Product Overview

The RE400a can be used with most portable music devices by using the standard mini-stereo plug. RE400a can provide excellent sound for calls and listening to music. Note that its operation will vary depending on your particular mobile phone.

Phone model/ Operation	Android Mobile Phones
Accept the call	Press the middle button once
End the call	Press the middle button once
Music Play / Pause	Press the middle button once

Key Features & Specifications

- Designed for Android
- Titanium coated 8.5mm drivers custom designed by HIFIMAN
- Powerful Neodymium magnets for high efficiency
- Oxygen-Free Copper Cabling
- Advanced ergonomics for comfort and extended listening
- Compact size, stylish light weight design
- 3.5mm mini plug
- Frequency Response: 15Hz-22kHz
- Impedance: 32Ω
- Sensitivity: 102 dB
- Rated: 10mW
- Maximum Input: 30mW
- Weight: 0.55Oz (15.8g)

Contents

- (7) Pair Silicone Tips
- (10) Filters (helps protect the earphone's inner components from dust)
- (1) Clip (affix the cable to a shirt or jacket to minimize cable noise)
- (1) Earphone Carry Pouch

How To Wear

Before using your earphones, make sure the volume is down on your device. There is a small (R) and (L) on the black stress relief of the earphones denoting the right and left channels.

Place earphone in your ear canal and using a gentle twisting motion push it into your ear until you get a secure fit. The cable should exit straight down (fig.1). You may have to try different size ear tips to get the correct fit and level of comfort.

If you desire to wear the cable in the "over the ear" style (fig. 2), follow the steps above, but the cable should exit to the top at a slight angle. You may need to adjust the angle to get the right level of comfort and secure fit.

Caution

- Do not use if you will be distracted or unaware when your full attention is required. Examples would be driving, biking, or walking or jogging in congested high traffic areas.
- Listening to audio at excessive volumes can cause permanent hearing damage. Enjoy at moderate volume levels.



fig.1 - Normal



fig.2 - Over the Ear

Product Warranty

HIFIMAN warrants this product to be free of defects in material or workmanship for a period of one year from the date of original retail purchase. If your product is found to be defective during the warranty period, HIFIMAN will, at its sole option, either repair the product or replace the product with a new or factory reconditioned or substantially equivalent model. This limited warranty does not apply to any defects attributable to damage beyond the reasonable control of HIFIMAN including damage caused by abuse, misuse, misapplication or modifications performed by anyone other than HIFIMAN.

Warranty

Should it becomes necessary to return your product to HIFIMAN for warranty or post-warranty service, please contact our customer service team to obtain an RA#. Return shipping to HIFIMAN or an authorized service facility is at the responsibility of the owner.

For any further information or questions, please contact your authorized HIFIMAN dealer, or contact us directly by email at customerservice@hifiman.com.



Connect With Us Online!



facebook.com/hifimanelectronics



twitter.com/hifimanofficial

Customer Service Tel: 1- 201-443-4626
E-mail: customerservice@hifiman.com
Website: www.hifiman.com